




LEGO

EV3

MINDSTORMS
EV3





when program starts

forever

wait until



1

is pressed?



set movement motors to

B

and

C



set movement speed to

100

%



move

forward

for

90

degrees



move

backward

for

90

degrees

